



## LEDTask™ LARC4 24VDC LED LightBar™ Installation Instructions

- 1) **Connecting the LARC4 24VDC LED LightBar™ to LTP24-90 24VDC Series Plug-in Power Supplies:** Connect the ARC4-PS-48 to DC-Jack connector provided with power supply using wire nuts or crimp connectors making sure to connect the positive (+) on the ARC4-PS-48 (denoted by white writing) and the positive (+) on the DC-Jack (denoted by white writing) together. Plug the ARC4-PS-48 into the LARC4 24VDC LightBar™ and plug DC-Jack into DC Plug from power supply (LTP24-90). Plug in power supply and turn on in-line switch.
- 2) **Connecting LARC4 24VDC LightBar™ to LTH 24VDC Series Hard-Wire Power Supplies:** Connect the ARC4-PS-48 to terminals of power supply making sure to connect the positive (+) on the ARC4-PS-48 (denoted by white writing) to the positive side of terminal block and the neutral (-) to the neutral side of terminal block.
- 3) **Mounting LARC4 24VDC LightBar™ to Surface:** Two options: Option (1) Direct mount; peel off RED paper to expose the double stick tape then carefully apply to surface in desired location. Option (2) Install mounting clips to desired surface then snap LightBar™ into place.

9830 W. 190th St. • Unit F • Mokena, IL 60448 • Toll-Free: (866) 671-0811 • FAX: (708) 478-2640 • [www.gmlighting.net](http://www.gmlighting.net)